


Right side view - ThinkPad T420, T420i

Other Location views

- Front view
- Left side view
- Bottom view
- Rear view
- Status indicators

Right side view



Index	Item	Description
1	Security keyhole	Your computer comes with a security keyhole. You can purchase a security cable and lock to fit this keyhole.
2	USB connectors	The Universal Serial Bus connector is used for connecting devices compatible with a USB interface, such as a printer or a digital camera. Note: Your computer is compatible with USB 1.1 and USB 2.0.
		The Universal Serial Bus connectors are used for connecting devices compatible with a USB interface, such as a printer or a digital camera.

3	eSATA/USB combo connector	<p>Note: Your computer is compatible with USB 1.1 and 2.0.</p> <p>You can also connect an external SATA device, such as an external hard disk drive, to this connector on some models.</p> <p>Note: To avoid damaging the connector, be careful when you attach a cable from the external SATA device to the connector.</p>
4	ExpressCard slot	Your computer has the ExpressCard slot for a 34 mm-wide card.
5	Media card reader slot	<p>Depending on the model, your computer may have a media card reader slot. The media card reader supports the following cards:</p> <ul style="list-style-type: none"> • SD card • SDHC card • SDXC card • MultiMediaCard <p>Note: Your computer does not support CPRM feature for SD card.</p>
6	Wireless radio switch	You can use this switch to disable the wireless radio of all the wireless devices on your computer.
7	Serial Ultrabay enhanced	<p>Your computer has a bay for serial Ultrabay™ enhanced devices. An optical drive is installed in the bay.</p> <p>Note: You can install a 9.5-mm-thick serial Ultrabay slim or a 12.7-mm-thick serial Ultrabay enhanced device in the serial Ultrabay enhanced.</p>
8	Combo audio jack	<p>To listen to the sound from your computer, connect a headphone or a headset that has a 3.5mm 4-pole plug, to the combo audio jack.</p> <p>Notes:</p> <ul style="list-style-type: none"> • If you are using a headset with a function switch, for example, a headset for an iPhone® mobile digital device, do not press this switch while using the headset. If you press it, the headset microphone will be disabled, and the internal microphone will be enabled instead. • The combo audio jack does not support a conventional microphone.

Search

 Couldn't find what you were looking fo 

Was this information helpful?

Your feedback helps to improve this site.

Alias ID:

Document ID: PD025332

Last Updated :17 Jun 2014

<https://support.lenovo.com/us/en/documents/pd025332>

Stay in touch



© 2016 Lenovo. All rights reserved

[Terms of Use](#) | [Privacy Policy](#) | [Site Map](#) | [Browser Compatibility](#)